

# FRANKENSTEIN V1.900

## NORMAL PROCEDURES

THIS DOCUMENT IS MADE FOR 3DOF  
MOTION SIMULATOR AND USAGE OF  
DIGITAL COMBAT FLIGHT SIMULATOR

APPROVED FOR VR USAGE AND  
BELT TENSION SYSTEM

PREFLIGHT 2

ENG STARTUP 2

MOTION SETUP 2

COMM  
PROCEDURES 2 | 3

BEFORE  
TAKEOFF 3

TAKEOFF 3

AFTER  
LANDING 3

### PREFLIGHT CHECKLIST

- |   |             |
|---|-------------|
| 1. LIGHTS .....                             | ON          |
| 2. PARKING BREAK SET .....                  | CHECK       |
| 3. LADDER .....                             | MOUNT       |
| 4. OBSTACLES CHECK .....                    | CHECK CLEAR |
| 5. VR SENSORS POSITION .....                | SET         |
| 6. DC BATTERIES VOLTAGE 24.1 - 26 VDC ..... | CHECK       |
| 7. DC MAIN SWITCH .....                     | OFF         |
| 8. VR SENSORS .....                         | PWR ON      |
| 9. EMG. BUTTON .....                        | TEST        |
| 10. DC & BELT TENSION PIT SWITCH .....      | OFF         |

### ENGINE STARTUP CHECKLIST

- |                            |    |
|----------------------------|----|
| 11. AC PWR .....           | ON |
| 12. AC FUSE SWITCH .....   | ON |
| 13. CPU MAIN SWITCH .....  | ON |
| 14. BANK ENG SWITCH .....  | ON |
| 15. PITCH ENG SWITCH ..... | ON |
| 16. DC MAIN SWITCH .....   | ON |
| ENTER COCKPIT              |    |

### MOTION SETUP CHECKLIST

- |   |   |
|---|---|
| 17. VR APP .....                        | START   |
| ALIGN HEADSET WITH SENSORS FOR 5sec     |   |
| 18. VR CONTROLLERS .....                | START & ALIGN                                 |
| CHECK CONTROLLERS ALIGNED POSITIV       |   |
| 19. VR MOTION CANCELLING                | CHECK BEHAVIOR, RESET ROOMALIGNMENT.... ALIGN |
| 20. DCS IMPORT PLUGIN .....             | START   |
| 21. RUDDER, THROTTLE, STICK INPUT ..... | CHECK   |
| 22. XSIM EXTRACTOR .....                | START   |
| 23. XSIM CONVERTER .....                | START   |

### COMM SETUP CHECKLIST

- |                                     |       |
|-------------------------------------|-------|
| 24. DLAN CONNECT .....              | CHECK |
| 25. VOICE ATTACK .....              | START |
| 26. SRS RADIO CHECK CONNECTED ..... | START |
| 27. TS RADIO .....                  | START |

### COMM SETUP CHECKLIST ( CONTINUED )

- |   |       |
|---|-------|
| 28. MIC AUDIO TRANSMIT / RECEIVE / VOLUME ..... | CHECK |
| 29. SUB AUDIO & BUTKICKER .....                 | CHECK |

### BEFORE TAKEOFF CHECKLIST

- |  |                |
|--|----------------|
| 30. SEATBELTS CHECK HIP BELT ALIGN   CHECK TENSION ..... | FASTEN & LOCK  |
| 31. DCS SIMULATOR CONNECT TO SERVER .....                | START          |
| 32. VA COMMANDS .....                                    | CHECK          |
| 33. SRS CONNECTED .....                                  | CHECK          |
| 34. XSIM DCS VALUE INPUTS .....                          | VALIDE         |
| 35. DC ENGINE MAIN PIT SWITCH .....                      | ON             |
| 36. BELT TENSION PIT SWITCH .....                        | ON             |
| 37. XSIM CONVERTER MOTION .....                          | START          |
| 38. AIR CONDITION .....                                  | AS REQU        |
| 39. VR HEADSET AND CHINBELT .....                        | MOUNT & FASTEN |
| 40. VR CONTROLLER .....                                  | MOUNT & FASTEN |
| 41. INGAME AIRCRAFT .....                                | SPOOLING       |

### TAKEOFF CHECKLIST

- |                            |          |
|----------------------------|----------|
| 42. LADDER .....           | DISMOUNT |
| 43. BREAK / AXISTEST ..... | PERFORM  |
| 44. PARKING BREAK .....    | RELEASE  |
| 45. INGAME AIRCRAFT .....  | TAKEOFF  |

### AFTER LANDING CHECKLIST

- |                                     |       |
|-------------------------------------|-------|
| 46. PARKING BREAK .....             | SET   |
| 47. DC ENGINE MAIN PIT SWITCH ..... | OFF   |
| 48. BELT TENSION PIT SWITCH .....   | OFF   |
| 49. LADDER .....                    | MOUNT |
| 50. XSIM CONVERTER MOTION .....     | STOP  |
| 51. INGAME AIRCRAFT .....           | QUIT  |
| 52. AIRCONDITION .....              | OFF   |
| 53. DC MAIN SWITCH .....            | OFF   |